

# SAM Configuration Manual

Ordering Number: 9032 011 987

Issue November 14, 2000

This version replaces all previous versions of this document. It also replaces the SAM System User's Manual (1997). Inmotion Technologies and ACC Motion have made every effort to insure this document is complete and accurate at the time of printing. In accordance with our policy of continuing product improvement, all data in this document is subject to change or correction without prior notice.

ACC Motion SA  
Zone industrielle La Rippe  
CH-1303 Pentha  
Switzerland

**P/n 9032 011 987**  
**Issue November 14, 2000**

© 1995 - 2000  
by ACC Motion SA  
All rights reserved



# Table of Contents

Table of Contents .....	3
List of Figures .....	5
List of Tables.....	6
Introduction .....	7
Scope of this Manual .....	7
Related Documents .....	7
Intended Use of SAM Products .....	7
Personal Safety .....	7
Warnings, Cautions and Information Notices .....	8
SAM Tools .....	9
Preliminary Remark .....	9
Installing SAM Tools.....	9
PC Hardware Platform .....	9
Installation for multi-version use.....	9
Getting Started with SAM Tools .....	11
Top Level Window.....	11
SAM Tools Subdirectories and File Extensions .....	12
Parameters .....	13
Downloading Parameters.....	13
Uploading Parameters .....	14
Upgrading Boot/Firmware.....	14
Replacing a SAM drive .....	15
Control Panels .....	15
Overview .....	15
ACC Standard Control Panels .....	16
Control Panel Components and their Operation .....	16
Activating a Control Panel.....	18
Creating a New Control Panel.....	18
Trace .....	20
ACC Standard Trace Setups.....	20
Producing a Trace .....	20
Interpreting and utilizing the Trace Display.....	22
Trace Markers .....	23
Grid.....	24
Trace Zoom Feature .....	24
Test Device.....	25
SAM Operating Software .....	26
Introduction .....	26
Definitions .....	27
Commands Manager.....	27
Motion Generator .....	27
Position Controller .....	27
Position Measurement .....	28
Current Controller.....	28
Status Registers .....	28

Operating States.....	29
Initialization.....	30
Run-Mode.....	30
SAM Position Controller - Its Tuning .....	31
Introduction .....	31
SAM Position Controller Principles.....	31
Short Description.....	31
Software Objects regarding Position Control .....	31
Some Theory regarding PD Position Control.....	33
PD Controller Performance verses Tuning .....	35
Some Theory regarding PID Position Control.....	36
PID Controller Performance verses Tuning .....	37
Some Theory regarding Feed-Forward Compensation .....	39
Benefits of using Feed-Forward – an example .....	39
Converting SAM Controller Parameters to “usual” units.....	41
SAM Drive Tuning Procedure.....	42
Overview .....	42
Preliminaries to Tuning .....	42
Select the Position Controller Operating Mode.....	43
PD Controller Adjustment Procedure.....	43
PID Controller Adjustment Procedure.....	47
Feed-forward Compensation Adjustment Procedure.....	49
Torque Mode Adjustments.....	51
Free Mode Adjustments .....	51
Emergency STOP Functions .....	52
Overview.....	52
Error Response .....	52
User Safety Inputs.....	52
Fatal Error Output .....	52
Brake Output Option .....	53
Status and Display.....	53
STOP 0.....	54
Activation.....	54
Execution.....	55
STOP 1.....	56
Activation.....	56
Execution.....	57
STOP2.....	58
Activation.....	58
Execution.....	59
USER SIGNAL .....	60
Activation.....	60
Execution.....	60
Fatal Error.....	61
SAM Brake Option.....	61
Description .....	61
Brake handling (brake enabled).....	62
Brake Object (class Cbrake) .....	62
Parameters related to Brake Option .....	62
Brake behavior related to ENABLED field .....	63
Brake error .....	63

Checking SAM-to-Motor Wiring .....	64
Motor and Feedback Wiring Errors .....	64
Checking Procedure .....	64

## List of Figures

Figure 1	Multi-version structure .....	9
Figure 2	SAM Tools Top Level Window .....	11
Figure 3	Control Panel with Component types Identified .....	17
Figure 4	New Dialog Box .....	19
Figure 5	Trace Commands Dialog Box .....	21
Figure 6	Trace Control Panel .....	22
Figure 7	Trace window .....	23
Figure 8	Test Device "Analog" panel .....	25
Figure 9	SAM Drive Software Functions .....	26
Figure 10	Position Controller Functional Diagram .....	27
Figure 11	Operating software Initialization phase .....	29
Figure 12	PD Position Controller .....	32
Figure 13	PD Control - Critically Damped Response .....	35
Figure 14	PD Control - Over damped Response .....	35
Figure 15	PD Control - Under damped Response .....	36
Figure 16	PID Control - Critically Damped Response .....	37
Figure 17	PID Control - Response with increased Cutoff Frequencies .....	37
Figure 18	PID Control - Over-damped Response .....	38
Figure 19	PID Control - Under-damped Response .....	38
Figure 20	PID Control - Under-damped Response .....	38
Figure 21	PD Axis Response without Feed-forward Compensation .....	39
Figure 22	PID Axis Response without Feed-forward Compensation .....	40
Figure 23	PD Axis Respond with Feed-forward Compensation .....	40
Figure 24	Tuning Control Panel with Least Significant digit of M_Stop0_AB Designated .....	44
Figure 25	Reference Waveforms for Proportional plus Derivative Tuning Step 17. ....	46
Figure 26	Example waveforms for Step 6. ....	48
Figure 27	Static friction compensation examples for step 8. ....	49
Figure 28	Viscous friction compensation examples for step 13. ....	50
Figure 29	Inertia compensation examples for Step 17 .....	51
Figure 30	STOP0 Activation .....	54
Figure 31	STOP0 Execution .....	55
Figure 32	STOP1 Activation .....	56
Figure 33	STOP1 Execution .....	57
Figure 34	STOP2 Activation .....	58
Figure 35	STOP2 Execution .....	59
Figure 36	USER SIGNAL Activation .....	60
Figure 37	STOP2 Execution .....	60
Figure 38	Brake Option Functional Diagram .....	61

## List of Tables

Table 1	Description of Components of SAM Tools Main Window Components.	11
Table 2	SAM Tools Subdirectory and file extension conventions .....	12
Table 3	ACC Standard Upload Templates (vv = version number, i.e. all20xx.spa for version 2.0) .....	14
Table 4	ACC Standard Panels (not available in all software versions; refer to \ACC\Socatool\Panels sub-directory content.) .....	16
Table 5	List of ACC Standard Traces .....	20
Table 6	Most interesting variables to trace *) it represents the pipe_position of PAM .....	22
Table 7	Short listing of Controller Parameters .....	32
Table 8	Short listing of Controller Fields; Measured position and velocity values (Mf_POS_MES and Mf_VEL_MES) are Main Sensor fields (and not Controller fields). Their prefix is thus "Mf_". .....	33
Table 9	Position Controller Modes .....	43
Table 10	SAM Default action mask (valid only for System 2.0_2) .....	53
Table 11	Brake Object fields .....	62
Table 12	Brake Object parameters .....	62
Table 13	Brake Object behavior .....	63
Table 14	Resolver Feedback and Motor Windings Wiring Verification Procedure .....	66
Table 15	POS_RES Values for ACC AC Servomotors .....	67

# Introduction

## Scope of this Manual

This SAM Configuration Manual presents procedures and guidelines for start-up of a SAM Drive in a PAM and SAM environment.

## Related Documents

The PAM and SAM System User's Handbook (in 6 parts) documents the Hardware. This SAM Configuration Manual contains information related to Software.

## Intended Use of SAM Products

The SAM product line constitutes a Power Drive System according to international standard IEC 611803, and Power Conversion Equipment according to UL standard 508C. Its intended use is for powering and controlling moving parts within industrial machines. SAM products are supplied as subassemblies to professional assemblers for incorporation into machines, apparatuses or systems. Assemblers are responsible for insuring that the SAM products are used for their intended purpose only, and for compliance with all applicable regulations.

According to the European Directive 80/392/EEC regarding machinery, putting a SAM Power Drive System into service is prohibited until the machinery into which it is to be incorporated has been declared in conformity with the provisions of this Directive.

## Personal Safety

The SAM product line is intended for connection to standard main voltages up to 480 VAC and for running motors up to 8000 rpm. High voltage and moving parts can cause severe or fatal injury. ACC Motion and Inmotion Technologies provide this and other manuals for assisting assemblers in using the products in a correct, efficient and safe manner.

Assemblers must insure that all persons responsible for design, test, maintenance and use of SAM have the proper professional skill and apparatus knowledge.

For compliance with the EC Directives and standards applicable to SAM products assemblers must read, understand and apply the specified procedures and practices regarding safety set forth in the PAM and SAM System User's Manual (6 parts).



---

When modifying PAM and SAM System Software, parameters, variables or any other configuration setting, the user must keep in mind that motors are powerful enough for causing fatal injuries to humans, and severe damage to machines.

---

## Warnings, Cautions and Information Notices

Special attention must be paid to the information presented in Warning, Caution and Information notices when they appear in this manual. Examples of these notices along with a description of their purposes follow:



An Information Box contains supplemental information or references to supplemental information on a topic.

---



The Stop Box highlights important conceptual or procedural details that must be understood and applied in order to successfully use the product.

---



A Warning informs the user of a hazard or potential hazard that could result in serious or fatal injury if the precaution or instruction given in the Warning notice is not observed.

---



# SAM Tools

## Preliminary Remark

All software components that are required for running a PAM and SAM System are supplied on the "ProMotion Collection" CD-rom. Each collection gathers several versions, together with several utilities and documentation.

The ProMotion Help file provides also for comprehensive information about SAM Tools.

## Installing SAM Tools

### PC Hardware Platform

#### Minimum PC Configuration Required

- 80486 processor
- 8 MB RAM memory
- 16 color VGA graphic adapter
- 1 serial port
- 15 MB disk space (for SAM Tools only), 30 MB for complete Promotion package
- Windows 95 or 98 installed

#### Recommended PC Configuration

- Pentium processor
- 16 MB RAM memory
- 16 color SVGA graphic adapter
- 1 serial port
- 15 MB disk space (for SAM Tools only), 30 MB for complete Promotion package
- Windows 95 or 98 installed

### Installation for multi-version use

The hierarchical structure proposed to be able to have different PAM & SAM systems and 32 bits new applications installed on a single PC is described in Figure 1. It is sharply recommended to use this structure to get the best efficiency.




Figure 1 Multi-version structure

### How to migrate from an old structure to the new structure

If your previous installation does not correspond to this structure, proceed as follow:

- 1) Quit the installation program.
- 2) Launch File Manager.
- 3) Remove all old versions of ProMotion on the PC.
- 4) Edit AUTOEXEC.BAT file and **remove** the following lines:
  - SET PAM=C:\SOCATool
  - SET PAMAGL=.
  - SET PAMSRCE=..\SRCE
  - SET PAMTEMP=C:\SOCATool\TEMP
  - SET PATH=xxx;C:\SOCATool (remove only the path to SOCATool)
- 5) Reboot the PC.
- 6) Restart the Master Setup.

During installation, a name for the root directory is requested. It **must be as short as possible** to guarantee that the old versions are running properly. By default, this directory name is "ACC". Longer directory name should not be used.

### How to install a ProMotion version

- 1) From the CD-Rom and Master Setup, choose the desired ProMotion version and follow the instructions.
- 2) From the CD-Rom without the Master Setup, explore the CD-ROM, choose the desired ProMotion version, open the directory called Disk1 and launch the application SETUP.EXE

### How to install a Service-Pack

A Service-Pack is an upgrade of a ProMotion version. It is designed for only one version of ProMotion.

Proceed like a ProMotion installation. Be sure that you install the corresponding Service-Pack.

### How to install several ProMotion versions

- 1) If any ProMotion version is already installed with the new structure, rename the "SOCATool" directory (with file manager) with an explicit name (i.e. V121 for ProMotion version 121).
- 2) Install the new ProMotion version as usually.
- 3) To use older PAM & SAM systems, it is enough to rename the directory «SOCATool» like above and to rename the selected directory in «SOCATool»

### How to install a Service-Pack on a structure with several ProMotion versions

Verify that the corresponding ProMotion version is installed and activated (The directory SOCATool corresponds to the selected ProMotion version)

## Setting up the COM Port

When SAM Tools is installed, COM1 port of the Service PC is selected by default. To select COM port 2 perform the following:

For Windows 95 and 98:

- 1) Access SAM Tools, properties
- 2) Select shortcuts tab
- 3) Under target add "COM2" separated by a space  
(i.e. xxxx\SAM TOOLS.EXE COM2).

## Getting Started with SAM Tools

### Top Level Window

#### Status and Display Components

Figure 2 shows the SAM Tools top level Window with the status and display components identified. Table 1 provides a description of these components.




Figure 2 SAM Tools Top Level Window

component	description
link status display	Displays status of SAM - Service PC communications link at time of last handshake
Bootware Version display	Bootware version residing in SAM Drive
Firmware version display	Firmware version residing in SAM Drive
SAM Drive status display	Displays current SAM Drive operating state
log message display	Most recent log message from SAM Drive
menu bar	Contains SAM Tools main pop-down menus
tool bar	Contains buttons for activating SAM Tool functions. Buttons for active functions appear in high contrast, colors on non-active buttons are subdued

Table 1 Description of Components of SAM Tools Main Window Components

### Tool Bar

When the mouse cursor is placed on an icon, a brief description of the buttons is displayed in a box.

### SAM Tools Subdirectories and File Extensions

During installation SAM Tools creates a number of subdirectories at the directory specified by the user at the beginning of the installation procedure. Different types of files as described in Table 2 are deposited into each of the subdirectories. ACC recommends retaining this structure as well as the file extension defined for each file type because software upgrades and revisions rely on this file structure.

sub directory name	ext.	description
firmware	.sfi	SAM Drive firmware files
bootware	.sbi	SAM Drive bootware files
params	.spa	SAM Drive and motor parameter files
panels	.pan	Creation files for ACC standard panels
cmds	.stc	ACC standard trace commands files
	.shc	host commands files (up to version 1.3)
support		conversion utility and C++ example programs
symbols	.syd	symbols dictionary
help		on-line help files
temp		temporary workspace for files created during SAM Tools execution

Table 2 SAM Tools Subdirectory and file extension conventions

We recommend that users create separate directories utilizing the same subdirectory and file extension structure for storing and archiving user-created parameter, panel and trace files.

## Parameters

SAM Tools provides the capability to download parameter files to a SAM Drive and upload parameters from a SAM drive into a file on the Service PC. The parameter upload and download features provide the means for recording, saving and replicating axis (software) configurations.

### Downloading Parameters

Parameters are downloaded into SAM Drive RAM memory where they remain until changed by command from a host PC/PLC or SAM Tools via the service port. Upon resetting the SAM Drive or upon power-up all parameters are initialized to values saved in flash memory.

Upon receipt of a “save parameters” command, the drive firmware copies an image of all parameters from RAM into flash memory. Parameter value changes are immediately accessible to the drive firmware; however, the firmware uses certain parameters only during initialization.



---

To be saved, parameters have to be copied into the flash memory using the “SAVE” command in the “Parameters” menu. Doing that, **existing parameter values are overwritten and lost.**

Existing SAM Drive parameter values may be preserved by uploading them to the service PC prior to downloading new parameters..

---

### Motor Parameters

Motor parameters must be downloaded to properly configure a SAM Drive for the motor it is controlling. To insure that a SAM Drive is properly configured for the motor it is controlling, this procedure should be performed whenever a SAM Drive is installed in a SAM system or whenever existing motor parameters are invalid or suspect.



---

When downloading motor parameters, be certain to select the correct file for the motor model connected to the SAM Drive.

Downloading incorrect motor parameters may cause unpredictable motor or drive behavior, and possibly be harmful to the drive or motor.

---

### Application related Parameters

Some parameters related to the application (position controller parameters, etc.) have to be tuned to obtain the best performances of the system. Refer to SAM Drive Tuning Procedure on page 42 for tuning procedure.

## Uploading Parameters

SAM Drive configurations (parameter sets) may be uploaded to a Service PC for viewing, editing, saving or other purposes using SAM Tools. During an upload, the complete set of parameters in RAM is uploaded. The uploaded parameter set when downloaded to an identical (same model) SAM Drive configures the drive exactly the same as the SAM Drive from which the parameter set was extracted.

The parameter values currently in RAM are uploaded to the Service PC where they are saved in the PARAMS subdirectory. SAM Tools assigns the filename "PARAMxxx.SPA where xxx is incremented by one each time SAM Tools saves a parameter set. The user may rename and relocate uploaded parameter sets using the standard **SAVE AS...** Windows file commands from the **FILE** menu.

Two types of parameter upload procedure are available; a standard upload and an "Upload with Template. In the "Upload with Template" operation, a user-created template attached to the parameter file controls which parameters are uploaded and which are not. Some pre-defined templates are available in ProMotion (see Table 3).

file name	upload
allvvxx.spa	all parameters in alphabetical order
appvvxx.spa	all parameters except drive specific ones

Table 3 ACC Standard Upload Templates  
(vv = version number, i.e. all20xx.spa for version 2.0)

## Upgrading Boot/Firmware

The following procedure is for upgrading bootware and firmware of SAM Drive (see Initialization on page 30 for definitions of bootware and firmware).

- 1) Upload parameters with template App15XX.SPA.
- 2) Save parameters as contextual name (e.g. Axis3.spa).
- 3) Stop the SAM.
- 4) Download the new bootware (SBEZxxxx.sbi).
- 5) Download the new firmware (SFEZxxxx.sfi)
- 6) Download saved parameters with contextual name.
- 7) Save all parameters.
- 8) Start the SAM.



If a 24 VDC supply failure occurs during writing of the bootware program into flash memory, the SAM Drive will become inoperative, requiring **factory repair**. Therefore, we recommend this procedure be performed only when absolutely required.



Upgrading bootware and firmware from System version 1.2\_xx or older requires a special procedure. Refer to Promotion.hlp help file for more information.

## Replacing a SAM drive

To be able to change a SAM drive in good conditions, it is recommended to have a saved parameters file of each axis. To create such a file, the following procedure is used.

- 1) Upload parameters with template App20XX.SPA.
- 2) Save parameters as contextual name (e.g. Axis3.spa).

Then it is very simple to change a SAM drive. Proceed as described in the "PAM and SAM System End-User's Manual".



---

If parameters are managed within the PAM application, this procedure is not necessary.

---



---

When replacing simultaneously the SAM software version, more information is available in ProMotion Help "How to install a new SAM System" topic".

---

## Control Panels

### Overview

A particularly powerful and useful feature of SAM Tools is the capability to create custom control panels on the Service PC monitor. Control panels provide direct, simplified access to a SAM Drive via the service port for tasks such as testing, monitoring or servicing an axis. Panels may be customized to the extent that buttons and displays have customized legends relevant to the machine or application or language of the country where used. Control panel attributes are stored in software files permitting control panels to be stored, recalled and recreated as needed.

A control panel is a customizable graphical interface to the SAM Drive, which provides the capability to interrogate and manipulate SAM parameters and fields. SAM Tools software provides the interface between a control panel and a SAM Drive, converting operator actions to the appropriate commands and updating the panel based on the drive's responses.

## ACC Standard Control Panels

ProMotion includes a library of standard panels useful for various aspects of SAM system monitoring, tuning and control. A description of the ACC standard panels is found in Table 4. These standard panels may also be used as the starting point for a user creating customized panels for a specific application.

file name	used to
analog.pan	define which variables to convert in analog outputs on Test Device
brake.pan	check brake behavior
endat.pan	display EnDat features of multiturn encoders and resolvers
hardinfo.pan	display hardware information
init_loc	check and initialize local position
init_mon	check and initialize 2 <sup>nd</sup> position feedback
init_pol.pan	check linear and some direct drive motors (System 2.0 and up)
io.pan	check and configure I/Os
magnali.pan	check linear and some direct drive motors (System 1.3 and 1.5)
main.pan	check general behavior
mask.pan	define Status Masks
mot_enco.pan	special panel for motors fitted with an sine-cosine encoder
motor.pan	view (and modify) motor parameters
move.pan	define and run repetitive movements on motor (System 1.3 and 1.5)
msampler.pan	check SAM interface to PAM-emitted position trajectory
regcur.pan	check Current Controller parameters
regsamp.pan	display fast input sampling
resolver.pan	check resolver and motor wiring and setting
sap_all.pan	display all SAM application variables
sensor.pan	display and define all feedback settings
stat_ab.pan	display Status A and B
stat_cd.pan	display Status C and D
st_com.pan	display EasyBus communication status
st_enco.pan	display Sine-Cosine encoder status
st_main.pan	display Main Status (status_m.pan on 1.3; statmain.pan on 1.5)
st_mes.pan	display internal resolver status (statmes.pan on Syst. 1.3 and 1.5)
status.pan	display all status fields
t_device.pan	define which variables to convert in analog outputs on Test Device
temper.pan	display temperatures and voltages
torq.pan	display and define SAM in Torque mode
tst_move.pan	define and run repetitive movements on motor (Syst. 2.0 and up)
tuning.pan	check and adjust Position Controller parameters
z_mark.pan	display reference mark of encoders

Table 4 ACC Standard Panels (not available in all software versions; refer to \ACC\Socatool\Panels sub-directory content.)

## Control Panel Components and their Operation

This section describes the components of a control panel and their operation. Figure 3 illustrates a sample control panel containing each of the available control panel component types with each component type labeled. Each of the panel component types is described in the following paragraphs.



## General Instructions for Control Panel Dialog Boxes

For most types of dialog boxes, SAM Tools places a border around the box when it has been opened and no other operations are allowed until the box is closed. The border color is red initially and changes to blue when the value is changed. Once the content of a box has been changed, press the ENTER key to update the corresponding SAM Drive parameter/field, or press ESC (the ESCAPE key) to restore the original value and exit the box.

In order to display the current value of SAM Drive fields/parameters a control panel must be updated. Control panels are automatically updated when initially opened and when reactivated. A user may update a control panel at any time by pressing the **REFRESH PANEL** button on the SAM Tools toolbar.



In order to display the current value of fields and parameters, a control panel must be updated. Control panels are automatically updated when initially opened and when re-activated. A user may update a control panel at any time by pressing the **REFRESH PANEL** button on the SAM Tools toolbar.

**Numeric Entry Box** - This type of box accepts numeric values. To change the value, click inside the box, then modify the existing value or enter a new value. The units of numeric entry boxes are the units of their corresponding fields in the SAM Drive. The units are generally included in the box label.

Numeric values are displayed in decimal, hexadecimal and scientific format. The format used is a function of the corresponding field and panel setup.




Figure 3 Control Panel with Component Types Identified

**Status Display Box** - These are single bit, read-only boxes used for displaying the value of a single SAM Status bit.

**Boolean Entry Box** - This type of box is used for controlling the state of Boolean inputs, which can only be true or false. An "x" in the check box means the input is in its true state, and a blank check box means the input is in its false state.

**List Box** - The value of the corresponding field/parameter highlighted in a contrasting color. Select an item from the drop-down list displayed in the box changes the value; then press ENTER on the keyboard.

**List Combo Box** - Displays a pop-down list of selections.

**Button** - Clicking on a button initiates one or more specific, pre-programmed actions. A button may operate in any of several ways depending on how it is specified in the control panel. The possibilities (see Figure 3) include buttons having no argument, buttons with fixed arguments (built into the button specification), buttons with an adjustable argument whose value is taken from a numeric entry box, and dual action buttons which produce an action when depressed and an action when released.

## Activating a Control Panel

Opening its file from the SAM Tools Log window activates a control panel. To open a control panel file, perform the following steps:

- 1) From the **FILE** menu select **OPEN**,
- 2) In the "File Open" dialog box, select the file name (including path) of the control panel to be activated, then press **OK**. All control panels have the file extension ".PAN".

If the desired control panel is listed on the SAM Tools recall list, it may be accessed as follows:

- 1) From the **FILE** menu, select **RECALL**, then select **PANELS** from the submenu.
- 2) From the pop-down list, select the desired panel.

More than one control panel may be open at a time, but only one panel may be active and only the active panel is responsive. The user may change the active panel by clicking in the panel to be activated.

The display boxes on a panel are updated automatically when the panel is opened or activated.

## Creating a New Control Panel

Creating a new control panel is a straightforward process, which requires performing the following steps:

- 1) Determine the functions required of the panel
- 2) Open a new panel document
- 3) Create buttons, displays and numeric entry boxes and specify their operation
- 4) Add any custom labeling or nomenclature desired.

### Determine the Functions Required

Panels are usually created for performing a specific task and include only those controls required for the task. This approach simplifies creation and use of the panel. The ProMotion Help, "SAM Parameters & Fields" topic provides a listing and description of all SAM Drive fields and parameters accessible by panel.



Although functions to stop motion and disable a SAM Drive output may be included on a panel, these functions cannot be considered “safe” as defined in IEC 60204-1 or IEC 61803. Safety functions must be implemented as specified in the PAM and SAM System User’s Handbook, Part 3 – Safety and Protective Functions.

### Opening a New Panel Document

- 1) From the SAM Tools Log window, select **FILE** then **NEW**.
- 2) In the “NEW” dialog box (see Figure 4) select **PANEL DOCUMENT**. A new window containing a blank panel is opened.
- 3) To assign a file name to the panel file, select **FILE** then **SAVE AS**. In the “FILE SAVE AS” dialog box, enter a file name and select a path.



When a new panel document is created, the panel window is opened in “Edit Mode”, which is the correct mode for creating and modifying panels. When utilizing a panel window as a control panel, the panel must be in “Execute Mode”.




Figure 4 New Dialog Box

### Creating Control Panel Components

Creating control panel components is a menu driven process in which buttons and boxes are created by selecting from a list of parameters, fields and methods accessible from control panels.

The nature of a field/parameter selected dictates the type(s) of entry or display box created. For buttons, the selected method dictates the button type(s) created.

### Creating Entry and Display Boxes

To create an entry or display box in an open Panel document, perform the following steps:

- 1) If the panel is not in “Edit Mode”, select **EDIT** from the **PANEL** menu.
- 2) Select **NEW CONTROL** from the **PANEL** menu.
- 3) Using the Object Browser, locate and select the field or parameter to insert into the control panel. Press **OK**.
- 4) In the “Choose Control Type” list box select a display box

## Trace

One of the most useful features of SAM Tools is its trace capability. The behavior of up to up to four SAM variables as a function of time may be captured, displayed, printed or saved for reference purposes. Trace setup information including trigger point specifications, sampling rate and trace variables are defined in a Trace Command file created using SAM Tools. Trace data is captured and saved in a reserved segment of SAM RAM memory, then uploaded on command to the Service PC where it may be displayed or saved and displayed at a later time.

The trace trigger point is defined by an expression, which may be a combination of numerical and logical values and operators. As with most digital storage oscilloscopes, the trace tool may be configured to display data before and after the trigger point. The sampling rate is adjustable over a wide range of values from processor cycle rate (8 kHz) to 1 (one) Hz.

## ACC Standard Trace Setups

The ProMotion includes a number of standard Trace command files for creating the Trace setups referenced in this manual. A description of these ACC standard trace setups is found in Table 5. These standard traces may also be used as the starting point for users creating custom traces for specific applications.


file name	description
marker.stc	trace SAM application markers
regcur.stc	current regulation
regpos.stc	used with tuning.pan to adjust feed-forward components of the Position Controller
resolver.stc	display resolver signals
resshift.stc	display resolver interface voltages
setpoint.stc	display set point from PAM
speed.stc	display speed reference
st_ab.stc	display status AB
st_cd.stc	display status CD
tetapos.stc	display measured position and polar angle
timing.stc	display internal SAM tasks duration
tmagn20.stc	display polar angle teach-in sequence
trace_io.stc	display inputs
tuning.stc	used with tuning.pan to adjust gains of the Position Controller

Table 5 List of ACC Standard Traces

## Producing a Trace

This paragraph describes the procedure for setting up a Trace using an existing Trace Command file:

- 1) From the Log window's **DEVICE** menu select **TRACE COMMANDS**.
- 2) In the "Trace Commands" dialog box (see Figure 5) press **LOAD**. In the "Open" dialog box, select the subdirectory containing the trace commands file to be utilized. Trace Command files have the file extension ".STC". Click **OK**.

- 3) The selected trace command file (see Figure 5) is now displayed in the “Trace Commands” dialog box. It defines for each channel, the label and the type, the address and the size of the variable to display. Table 6 shows the type and the size of the most interesting variables to trace. For addresses, as they are related to the firmware version, please use the browser for the DSP variables or refer to the “ProMotion.hlp” help file for the i960 variable. A “Trace” control panel (see Figure 6) is also displayed.
- 4) In the “Trace Commands” dialog box press **EXECUTE** to setup the SAM Drive for capturing the trace data. The message “Execution Successful” appearing in the “Trace Commands” dialog box indicates successful setup of the SAM Drive.
- 5) Press **CLOSE** to close the “Trace Commands dialog box.
- 6) In the “Trace” control panel, press **START** to initiate the trigger.
- 7) When the Trace control panel displays **TRIGGERED** and **STOPPED** the trace data gathering operation is complete. On the “Trace” control panel press **UPLOAD** to upload the trace data to the Service PC for display. The trace data is also saved to a file in the TEMP subdirectory. SAM Tools assigns the name “TRACExxx.TRC (where xxx is the next number in sequence) to the trace file.
- 8) To initiate another trace operation utilizing the same trace setup, first press  on the SAM Tools toolbar to recall the “Trace” control panel, then press **START** to initiate another trace operation.




Figure 5 Trace Commands Dialog Box




Figure 6 Trace Control Panel

Related Field	Symbol	Mem. Type	Type	Units (1 lsb = ...)
Rf_SPEED_REF	SpeedRef	MEM_DSP_INT	INT16	0.915 t/min @ 8kHz
Rf_ACCEL_REF	AccelRef	MEM_DSP_INT	INT16	3433.23 t/min <sup>2</sup> @ 8kHz
Rf_POS_LAG_16	PosLag	MEM_DSP_INT	INT16	2 <sup>-16</sup> t
Rf_TORQ_FLOW	TorqFlow	MEM_DSP_INT	INT16	4096 = stall Torque
Rf_TORQ_QUIET	TorqQuiet	MEM_DSP_INT	INT16	4096 = stall Torque
Rf_TORQ_REF	TorqRef	MEM_DSP_INT	INT16	4096 = stall Torque
Rf_IKAN	Ikan	MEM_DSP_INT	INT16	
Af_UDCbus	UdcBus	MEM_DSP_INT	INT16	4096 = Udc max
Af_IQRef	IQRef	MEM_DSP_INT	INT16	4096 = I <sub>max</sub>
Af_IQMes	IQMes	MEM_DSP_INT	INT16	4096 = I <sub>max</sub>
Mf_SIN_A	Sina	MEM_DSP_INT	INT16	
Mf_COS_A	Cosa	MEM_DSP_INT	INT16	
Mf_POS_RES	PosResB	MEM_DSP_INT	INT16	2 <sup>-16</sup> t
Of_INPUTS_VALUES	Inputs	MEM_960	BIN16	
none*	Setpoint	MEM_960	INT32	27.94·10 <sup>-6</sup> t/min (CPU=2kHz)

Table 6 Most interesting variables to trace  
 \*) it represents the pipe\_position of PAM

Units depending on the working frequency (4 or 8 kHz) are calculated as follow:

**SpeedRef** given units in the filed list: 2<sup>-19</sup> t/POS REG period  
 we have then, at 8 kHz:

$$\frac{2^{-19}}{\left(\frac{1}{8000}\right)} \cdot 60 = 0.915 \text{ turn / min}$$

**AccelRef** given units in the filed list: 2<sup>-26</sup> t/POS REG period  
 we have then, at 8 kHz:

$$\frac{2^{-26}}{\left(\frac{1}{8000}\right)^2} \cdot 60^2 = 3433.23 \text{ turn / min}^2$$

**Setpoint** units are 2<sup>-32</sup> t/MAIN CPU period. MAIN CPU period is 2 kHz then:

$$\frac{2^{-32}}{\left(\frac{1}{2000}\right)} \cdot 60 = 27.94 \cdot 10^{-6} \text{ turn / min}$$

## Interpreting and utilizing the Trace Display

The trace display includes a number of useful features and capabilities to aid in measuring and analyzing the captured data including movable markers, an optional grid and zooming capability.

### Components of Basic Trace Display

This paragraph provides a description of the components of a trace and how they are utilized and interpreted. Figure 7 shows a two variables trace with components identified.




Figure 7 Trace window

**Time Scale** - Shows the time reference for the trace data. The time scale is a function of the sample rate specified in the Trace Command file associated with the trace data. Time  $t = 0$  is the trigger point (point at which the trigger condition is satisfied). The pre and post trigger percentages displayed are set by command in the Trace Command file.

**Variable Scale** - The graphical display of each variable is adjusted automatically to show the full excursion of the variable over the sampling interval within the available vertical space and the variable scale shows the relationship between vertical amplitude of the variable and it's actual value. Units of the variable scale are the units of the variable (see Table 6).

Note that the variable scale for successive traces of a variable may be different if the total excursion of the variable changes.

**Trigger Point** - This dashed vertical line indicates the point at which the trigger condition is satisfied. This point becomes the time origin ( $t = 0$ ) for the trace.

**Trigger Position** - The position (or value) of each variable at the trigger point.

**Channel Title** - This is a four part expression comprised of a channel label, memory type, memory address and data type. Channel label is a user-defined name for the variable, memory type and memory address define the location of the variable is the SAM Drive's RAM memory and data type defines the format (i.e. integer, real, etc.) of the variable.

**Channel Graphical Area** - Portion of the channel in which trace data is plotted. The areas at the left and right extremes of each channel graph are outside the graphical area.

## Trace Markers

Two trace markers (M1 & M2) are available for making precise measurements from graphical trace data. The value of each variable at it's point of intersection with the marker is displayed along with the position (it time) of each marker. In addition the delta  $t$  and delta values for each channel are displayed on the trace.

To position a trace marker on a displayed trace, position the mouse pointer over the desired point, hold down the SHIFT key, then click on the left or right mouse button (left button to position M1 or right button for M2). Markers are not saved when a trace file is closed.

Markers may be alternately hidden or shown by selecting **MARKER** from the **VIEW** menu.

## Grid

A grid may be alternately applied or removed from the graphical display area of a trace by selecting **GRID** from the **VIEW** menu.

## Trace Zoom Feature

The zoom feature may be used to magnify a portion of a trace. Two zoom modes, time zoom and area zoom are available. Time zoom takes a selected portion of the trace and expands it horizontally to fill the trace display area. Area zoom expands the selected area of a single channel to fill the display area. When a trace is expanded the time and variable scales are adjusted accordingly to retain a calibrated image. Any sector of a trace within the graphical area of a channel may be zoomed. When zooming is possible a magnifying glass symbol is displayed beside the mouse pointer. Zoomed traces may be printed but not saved.

Perform the following steps to time zoom a trace:

- 1) Position the mouse pointer inside the graphical area of a channel at one end of the area to be expanded. The magnifying glass symbol must be visible next to the mouse pointer indicating that zooming is possible.
- 2) Press and hold the left mouse button.
- 3) While holding the mouse button down, move the mouse pointer left or right and up or down as necessary to "box in" the area to be expanded.
- 4) Release the mouse button. An expanded display of the selected area is created.
- 5) To return to the previous version of the trace select **PREVIOUS** from the **VIEW** menu. To return to the original version of the trace, select **ORIGINAL** from the **VIEW** menu.

In order to zoom on area of a trace, perform the following steps:

- 1) Position the mouse pointer inside the graphical area of a channel at one corner of the area to be expanded. The magnifying glass symbol must be visible next to the mouse pointer indicating that zooming is possible.
- 2) Press and hold the right mouse button.
- 3) While holding the mouse button down, move the mouse pointer left or right to the other end of the area to be expanded. As the pointer is moved a box encloses the selected area.
- 4) Release the mouse button. An expanded display of the selected area is created.
- 5) To return to the previous version of the trace select **PREVIOUS** from the **VIEW** menu. To return to the original version of the trace, select **ORIGINAL** from the **VIEW** menu.



## Test Device

The SAM Test Device is an optional tool, which can be inserted between the SAM RS232 servicing plug and the Service PC cable. With this device, two internal variables can be available on two analog outputs, i.e. for monitoring on an oscilloscope.

The “analog.pan/t\_device.pan” panel (see Figure 8) allows selecting which variable is displayed on which output.




Figure 8 Test Device “Analog” panel

DSP variables can be selected directly within the scrolling list.

i960 variables have to be defined with their addresses and their size (see ProMotion.hlp, “Trace information” section).

For both types of variable (DSP and i960) the scale factor (units/volts) has to be defined as in following examples:

**SpeedRef** given units in the filed list are  
 $2^{-19}$  t/POS REG period  
 which give at 8 kHz: 0.915 t/min.

It means that 1 lsb of the SpeedRef variable represents 0.915 t/min. Then, if we want, for example 1V/1000 t/min, scale factor will be:

$$\frac{1000}{0.915} = 1092.26 \text{ units / volt}$$

**PosLag** given units in the filed list are  
 $2^{-16}$  t  
 which give:  $5.49 \cdot 10^{-3}$  degree.

It means that 1 lsb of the PosLag variable represents  $5.49 \cdot 10^{-3}$  degree. Then, if we want, for example 1V/1deg, scale factor will be:

$$\frac{1}{5.49 \cdot 10^{-3}} = 182 \text{ units / volt}$$

# SAM Operating Software

## Introduction

The functionality of SAM Drive comes largely from its resident operating software. The functions are distributed among its two microprocessors. Figure 9 highlights the principal software functions and shows links between software and hardware functions.




Figure 9 SAM Drive Software Functions

## Definitions

### Commands Manager

The Commands Manager handles communications with PAM, application program (Sequence) execution and coordinates activities within the SAM. Using a dedicated RS-232 port, it communicates with a PC running SAM Tools and a “Test Device” accessory.

### Motion Generator

The Motion Generator executes those portions of various pipe block functions, which are implemented at the axis level. Secondly, it generates independent motion profiles including point to point and continuous motions in response to commands and parameters from the application program.

A “Limiter” compares the flow of motion data against limiting values of positive and negative travel, speed, acceleration/deceleration, torque and direction imposed by the application. Whenever a trajectory values exceeds a limit, the limiter sets an appropriate status bit, which is normally used to stop the motion. The user normally establishes limiter parameters, based on the application’s requirements.

### Position Controller

The Position Controller (see Figure 10) is a firmware algorithm that provides field proven, closed loop PID control with enhanced feed-forward compensation. A notch filter, which can be activated and tuned by parameter, may be utilized to improve system performance in the presence of strong torque disturbances when a mechanical resonance frequency might otherwise limit the closed loop pass-band.

The Position Controller, employing totally digital techniques, provides the benefits of precision and repeatability. Two SAM Drives with identical tuning parameters respond identically in the same axis environment.

Other Controller operating modes including speed controller, open-loop vector-controlled operation and direct torque control can be selected. A position feedback device (typically a resolver or encoder) provides velocity and position feedback to the Position Controller.




Figure 10 Position Controller Functional Diagram

## Position Measurement

The Position Measurement function, utilizing input from the Feedback Interface, provides measured position and velocity data. Position feedback is used by the Current Controller for commutating the motor currents and by the Position Controller for regulating motor speed and position.

## Current Controller

The Current Controller is a closed loop controller, which supplies a three-phase pulse width, and sine wave modulated current command to the Power Stage. It monitors the output currents and regulates the direct ( $I_D$ ) and transverse ( $I_G$ ) current components. The Current Controller employs totally digital control, which provides improved performance and repeatability compared to standard analog technology. Control algorithms for AC synchronous motors (AC Servo motors) and asynchronous motors (AC induction motors) are built in and selectable by parameter.

A downloadable parameter file, which correctly configures the Current Controller and Power Stage, is available for every model servomotor that is available together with the PAM and SAM System. Configuration files for other types of motors are also available.

Built-in thermal load modeling of the axis motor utilizing motor and drive parameters provides reliable and responsive motor overload protection under all operating conditions.

## Status Registers

Four 16-bit status registers provide a complete picture of SAM current operational state with respect to error, fault and alarm conditions. For easier and quicker event detection, a fifth 16 bit Main Status register provides a summary picture of SAM current operational state.

## Operating States

SAM software controls in a very strict way in which “state” the Drive is. Depending on the actual state, several actions and transitions are possible and others are not.

SAM state is displayed on its front-panel.




Figure 11 Operating software Initialization phase

## Initialization

A compressed version of the operating software (also named “Firmware”) along with an uncompressed copy of a Boot-up program (also named “Bootware”) and all parameters reside in nonvolatile flash EEPROM. Upon startup, the Bootware is copied into RAM and executed. It performs some hardware and communication initialization, then copies the Firmware (decompressed) and parameters into RAM. CRC checking is used to verify the integrity of the RAM contents.

Execution of the operating software begins with the Configuration phase during which all SAM Drive adjustments and settings are established digitally using either default parameter values from flash EEPROM, or configuration files previously downloaded from a host or service PC running SAM Tools. SAM may be commanded to “save” parameters, upon which the current values of all parameters are stored in flash EEPROM. A host or service PC may upload a complete parameter set for archiving a configuration.

## Run-Mode

Upon completion of the Configuration phase, the operating software enters the run-mode phase, which handles communication with the host, commands execution and finally controlling the motor.

# SAM Position Controller - Its Tuning

## Introduction

Section titled “SAM Position Controller Principles” discusses and illustrates the concepts, terms and equations utilized in the tuning procedures. A block diagram and description of the Position Controller is included in this introductory section.

This chapter presents next step by step procedures for tuning a SAM Drive.

## SAM Position Controller Principles

### Short Description

SAM Drives incorporate a modern, flexible closed-loop controller (called the “Controller” or “Position Controller”) which is responsible for keeping an axis on it's required speed and position trajectories.

**Closed-loop control** is required for compensating indeterminate disturbances (disturbances of unpredictable magnitude or timing). If indeterminate disturbances are significant relative to the required accuracy, only comparatively high PID loop gains can provide the necessary precision. However, with higher PID loop gains comes the classic compromise of precision vs. stability. Position overshoots are also very common.

The effects of known disturbances such as inertia (during acceleration), friction and others are most easily eliminated using **feed-forward compensation** rather than high position loop gain. If indeterminate disturbances are small, the required accuracy may be achieved mainly using feed-forward compensation with lower controller loop gains and less chance for stability problems. The integral gain can also be set to zero, as in a simpler PD control scheme, so that no position overshoot occurs.

### Software Objects regarding Position Control

The Controller is software based and employs digital signal processing techniques. The Controller is tuned by adjusting its parameters to achieve desired performance. Using standard control panels and traces supplied with SAM Tools, drive tuning is accomplished quickly and easily following the procedure in this chapter.

Figure 12 shows a functional diagram of the Position Controller. Parameters and fields accessible to the user are labeled.




Figure 12 PD Position Controller

A short listing and description of Controller parameters is found in Table 7, such as set gains, thresholds or clamping limits for various functional elements of the Controller. **Detailed list is available in ProMotion Help “SAM Parameters and Fields” topic.**

The more dynamic Controller input and output variables are defined as fields, and presented in Table 8.

All Controller parameters begin with the prefix “R\_” or “Ri\_” (e.g. R\_PGain). Controller fields prefix is Rf.

parameter name	description
R_DGain	sets derivative gain of controller
R_ExtTorq	torque input when controller is in external command mode
R_IGain	integral gain of controller
R_Inertia	sets inertia feed-forward compensation gain
R_MaxPosLag	sets threshold value for position lag error
R_MaxTorq	sets upper torque limit
R_MaxVelLag	sets threshold value for velocity lag error
R_PGain	sets proportional gain of controller
RStatFricTorq	sets static friction torque feed-forward compensation value
RViscFricTorq	sets viscous friction torque feed-forward compensation gain
Ri_RegMode	sets Controller working mode:

Table 7 Short listing of Controller Parameters



field name	description
Rf_ACC_REF	acceleration command from TMP Generator
Rf_POS_LAG	position error
Mf_POS_MES*	axis position from position feedback device
Rf_POS_REF	position command from TMP Generator
Rf_TORQ_FEEDF	torque feed-forward command
Rf_TORQ_FLOW	torque flow command from external flow input
Rf_TORQ_QUIET	component of torque command
Rf_TORQ_REF	composite torque command
Rf_TORQ_LIM	current torque limit
Rf_VEL_LAG	velocity error
Mf_VEL_MES*	measured axis velocity
Rf_VEL_REF	velocity command from TMP Generator

*Table 8 Short listing of Controller Fields;  
Measured position and velocity values (Mf\_POS\_MES and Mf\_VEL\_MES) are  
Main Sensor fields (and not Controller fields). Their prefix is thus "Mf\_".*

### Some Theory regarding PD Position Control

Referring to the block diagram of a proportional plus derivative control system shown in Figure 12, let us first define the following terms:

$K_D$	speed loop gain
$K_P$	position loop gain
speed	speed feedback, the measured speed of the axis
position	position feedback, the measured position of the axis
speed lag	difference between commanded and measured speed
position lag	difference between commanded and measured position
position ref.	commanded or set point position
speed ref.	commanded or set point speed
J	motor plus load inertia

The tracking precision, that is the ability of the axis to remain on it's trajectory in the face of disturbances, depends on position loop gain; however, this loop by itself is unstable due to the double integration. The speed loop serves to stabilize the system. For a given axis configuration, position loop gain, speed loop gain and their ratio have a range of values which produce optimum axis performance. Outside this range tracking precision degrades or the axis becomes unstable.

From control system theory two terms, "speed loop cutoff frequency" ( $F_{CV}$ ) and "position loop cutoff frequency" ( $F_{CP}$ ), are very useful for determining optimum values of position loop gain and speed loop gain. The cutoff frequency is the frequency at which the output amplitude is reduced by a factor of 2 (6 dB) compared to the output amplitude at zero Hertz.

For a sinusoidal **speed reference**, at cutoff frequency ( $F_{CV}$ ):

$$speed = \frac{speedreference}{2} = speedlag$$

$$speed = \frac{1}{2\pi \bullet F_{CV}} \bullet acceleration$$

$$acceleration = \frac{speedlag \bullet K_d}{J}$$

Therefore:

$$F_{CV} = \frac{1}{2\pi} \bullet \frac{K_d}{J}$$

For the position loop with a double integral,

$$position = \left( \frac{1}{2\pi \bullet F_{CP}} \right)^2 \bullet acceleration$$

Therefore:

$$F_{CP} = \frac{1}{2\pi} \bullet \sqrt{\frac{K_p}{J}}$$

The ratio  $\frac{F_{CV}}{F_{CP}}$  is called the damping ratio.

When the damping ratio is  $> 1$  a system is referred to as over-damped, when the damping ratio is  $< 1$  a system is under-damped.

When the damping ratio = 1 the system is critically damped. A critically damped system provides classically stable operation with optimum response (best compromise for minimum overshoot with short settling time). In that case:

$$F_{CV} = F_{CP}$$

Then,

$$\sqrt{\frac{K_p}{J}} = \frac{K_d}{J}$$

Therefore:

$$K_p = \frac{K_d^2}{J}$$

This relationship is important because it shows that for constant damping,  $K_p$  is proportional to  $K_d^2$ . This means that in order to maximize  $K_p$  (and therefore minimize position lag) while maintaining stability,  $K_d$  must be made as large as possible.

In practice,  $K_d$  is limited by several factors including the SAM Drive current loop bandwidth which is directly related to the PWM frequency selected for the drive (standard: 8 kHz; optional: 4 kHz). Other factors including resonance frequency of the axis mechanics and signal to noise ratio of the speed measurement limit how large  $K_d$  can be.

In practice  $K_d$  is increased to the point where the axis goes into sustained oscillation, then reduced by a factor of 2 to obtain good speed loop stability.  $K_p$  is

then determined using the relationship  $K_p = \frac{K_d^2}{J}$  and fine tuned, if desired, using a step response test.

### PD Controller Performance verses Tuning

Figure 13 shows the response of a SAM Drive and AHR 142C6 motor to a step torque disturbance equal to stall torque of the motor. In Figure 13, the Controller is tuned for critically damped response ( $F_{CP} = F_{CV} = 50 \text{ Hz}$ ). Note that the motor overshoots once by about 20% then settles to a steady state position lag of 1050 units ( $\sim 5.8$  degree).




Figure 13 PD Control - Critically Damped Response

Figure 14 shows the same system response with  $F_{CV} = 50 \text{ Hz}$  and  $F_{CP} = 25 \text{ Hz}$  (damping ratio = 2, over-damped). Note that at this damping ratio there is no overshoot; however, the settling time is longer and the steady state position lag is four times greater due to the reduction in position loop gain.




Figure 14 PD Control - Over damped Response

Figure 15 shows the same system response when  $F_{CV} = 50$  Hz and  $F_{CP} = 100$  Hz (damping ratio = 0.5, under-damped response). Note that the overshoot is significantly larger and settling time has increased, but steady state position lag is smaller due to increased position loop gain.




Figure 15 PD Control - Under damped Response

### Some Theory regarding PID Position Control

PID control is similar to proportional plus derivative control but includes an additional loop with a gain ( $K_i$ ) and an integrator. This additional loop serves to eliminate static position lags resulting from static disturbances. This loop can only correct static disturbances or disturbances with frequencies below its cutoff frequency ( $F_{Ci}$ ). This loop is by itself unstable due to the three integrations and is stabilized by the other two loops.

Unlike the proportional plus derivative case,  $F_{Ci}$  cannot be set equal to  $F_{CP}$ . Stable operation is typically obtained at:

$$F_{cv} = F_{cp}$$

$$F_{ci} = 0.63 \bullet F_{cp}$$

with:

$$K_i = 0.25 \bullet \frac{K_p^{1.5}}{\sqrt{J}}$$

Higher system stability is achieved by setting  $F_{CP} < F_{CV}$  and  $F_{Ci} < 0.63 \bullet F_{CP}$ . The system response may be fine tuned using a step response test.

## PID Controller Performance versus Tuning

Figure 16 shows the effect of adding integral control to a proportional plus derivative control loop. In this illustration  $F_{CP}$  and  $F_{CV}$  are the same (50 Hz) as the critically damped PD case (see Figure 13), and  $F_{ci} = 0.63 \cdot F_{cp} = 32 \text{ Hz}$ .

Note that the initial response (for the first 10 ms) is about the same as Figure 13, but, as a result of the integral feedback, static position lag is reduced to zero.




Figure 16 PID Control - Critically Damped Response

In Figure 17,  $F_{CV}=F_{CP}=100\text{Hz}$  and  $F_{Ci}=63\text{Hz}$ . All three cutoff frequencies are increased by 100% compared to Figure 16, resulting in a significant reduction of position lag and settling time. Because the ratios of cutoff frequencies remain the same, the general shape of Figure 16 is the same as Figure 17.




Figure 17 PID Control - Response with increased Cutoff Frequencies

Figure 18 shows the effect of reducing  $F_{cp}$  to 35 Hz.  $F_{ci}$  is reduced to 20 Hz in order to retain  $F_{ci} = 0.63 \bullet F_{cp}$ . The reduction in  $F_{ci}$  and  $F_{cp}$  increases stability but slows the response.




Figure 18 PID Control – Over-damped Response

Figure 19 shows decreased stability when  $F_{ci}$  is increased to 40 Hz, thus increasing  $F_{ci}/F_{cp}$  to 0.8, while keeping  $F_{cp} = F_{cv} = 50\text{Hz}$ .




Figure 19 PID Control - Under-damped Response

In Figure 20,  $F_{cp}$  is reduced to 35 Hz with  $F_{ci} = 32\text{Hz}$  and  $F_{ci}/F_{cp} = 0.91$ . The result once again is decreased stability.




Figure 20 PID Control - Under-damped Response

## Some Theory regarding Feed-Forward Compensation

When a driven system and its behavior are well known, it is possible to create a simplified mathematical model which takes into account the influences of disturbances such as weight, static and viscous friction and the effect of load inertia during acceleration/deceleration. With a degree of precision which increases the closer the model comes to reality, the torque necessary for each movement may be calculated and applied directly to the motor independent of any feedback. Due to its “open-loop” nature, feed-forward compensation does not contribute to axis instability and it is simple to setup. In many applications, utilization of feed-forward compensation provides improved trajectory tracking accuracy using a less complex Position Controller mode, with lower gains, improved stability, and no position overshoot. The Position Controller remains active. It functions to compensate for the remaining differences between the model and real system.

Figure 9 on page 26 shows SAM implementation of feed-forward compensation:

- For inertia compensation, a torque component proportional to acceleration is created
- For viscous friction, a torque component proportional to speed is added
- For “dry friction”, a constant torque component with sign based on the speed reference is summed into the composite torque command
- For weight, a torque component equal to a parameter setting is added

## Benefits of using Feed-Forward – an example

Figure 21 shows the response of a critically damped proportional plus derivative axis when commanded to move 1800 degrees (5 turns) at a velocity of 9000 degrees/sec. and an acceleration of 360,000 degrees/sec<sup>2</sup>. The upper trace of Figure 21 is the velocity profile of the move and the lower trace shows position lag.

Note that position lag increases significantly during the acceleration and deceleration portions of the move due to the effects of the motor plus load inertia which cannot be totally removed by the Controller's position loop gain. During the constant speed portion of the move, average position lag is approximately +50 due to the static and viscous friction produced by the motor and load. The AC component of position lag during the constant velocity portion of the move is due to the inherent cyclical error of the resolver providing position and velocity feedback for the axis.




Figure 21 PD Axis Response without Feed-forward Compensation

Figure 22 shows the same move with the Controller operating in PID mode and adjusted for optimum response. The action of the integral feedback loop tends to drive position lag toward zero during the intervals of constant acceleration and constant speed; however, the peak to peak position lag is not reduced.




Figure 22 PID Axis Response without Feed-forward Compensation

Figure 23 shown the axis response to the same move following introduction of feed-forward compensation in the Controller.

In this example, the Controller is configured as a proportional plus derivative controller with the same proportional and derivative gain settings as for Figure 21. Static friction, viscous friction and inertia compensation parameters, which were previously zero, have been adjusted to the correct values for the motor and its load. Due to the auto scaling feature of the SAM Tools Trace function, the position lag appears larger than previous examples, but peak to peak position lag is now approximately 110 (an **80% reduction**) and average position lag is nearly zero.




Figure 23 PD Axis Response with Feed-forward Compensation



### Converting SAM Controller Parameters to “usual” units

Listed below are the SAM system-specific equations and relationships corresponding to those listed in this general discussion of tuning principles.

$$K_D = R\_DGain \cdot \frac{M\_StallTorq}{2\pi \cdot 1000}$$

$$K_P = R\_PGain \cdot \frac{M\_StallTorq}{4\pi}$$

$$K_I = R\_IGain \cdot M\_StallTorq \cdot \frac{8000}{2\pi \cdot 512}$$

$$F_{cv} = \frac{1}{2\pi} \cdot R\_DGain \cdot \frac{M\_StallTorq}{J} \cdot \frac{1}{2\pi \cdot 1000}$$

$$F_{cp} = \frac{1}{2\pi} \cdot \sqrt{R\_PGain \cdot \frac{M\_StallTorq}{J} \cdot \frac{1}{4\pi}}$$

$$F_{ci} = \frac{1}{2\pi} \cdot \sqrt[3]{R\_IGain \cdot \frac{M\_StallTorq}{J} \cdot 1.35}$$

## SAM Drive Tuning Procedure

### Overview

This section presents step by step tuning procedures. Tuning parameters are entered and adjusted using standard control panels provided with SAM Tools. Axis responses are captured and displayed on a PC monitor using the SAM Tools traces feature.

### Preliminaries to Tuning

Prior to beginning any axis tuning procedure, the SAM Drive must be properly configured with the correct motor parameters for the axis configuration. Any fault or error conditions must be eliminated. A PC running SAM Tools and a SAM to Service PC test/monitoring cable (ACC p/n 9032 010 689) are required to perform the procedure.

To properly tune a SAM Drive the actual axis mechanical load should be connected to the motor. In that case the system integrator must be very careful for not ordering any motor movement that can be destructive or dangerous while tuning.

Load simulators (i.e. inertia wheels) are useful for preliminary setup, but are not recommended when performing final controller adjustments because they seldom duplicate the behavior of the actual axis load.

The axis load must be tightly coupled to the motor. Free-play or backlash between the motor and load complicates the tuning process and prevents satisfactory performance in most applications.

The optimum controller adjustment is not necessarily with all gain settings just below the point of instability. A preferable strategy is to adjust the Controller to a point where the desired performance is achieved with some additional margin.



The process of tuning may subject motors, SAM Drives and Dynamic Braking Resistors to conditions exceeding the operating conditions encountered during execution of the application for which the SAM system components were sized. SAM System components are protected against overloads, but system integrators must be cognizant of this possibility, and not operate the equipment outside its limits.



Motors may run faster or slower than expected, or in the opposite direction, or even go into oscillations.



**System integrators must take necessary precautions such as limiting maximum torque to prevent erratic motor operation from harming personnel or the driven equipment or the machine.**

## Select the Position Controller Operating Mode

The SAM Position Controller may be configured by parameter to operate in any of the modes listed in Table 9, which also summarizes important performance characteristics of each Controller mode. Select an operating mode based on the axis configuration and performance required then tune the Controller using the adjustment procedures for the operating mode selected.

Controller Mode	Performance Characteristics
PD position control	Classical PD (proportional plus derivative) control loop. Average speed lag is zero. Static position lag is proportional to disturbance torque.
PID position control	Classical PID (proportional plus integral plus derivative) control loop. Average speed lag is zero. Static position lag in response to a disturbance torque is zero.
torque control	Front end of Position Controller is disabled. Application controls torque output directly.
free	Position Controller produces a rotating current vector. This mode is used for motor wiring check.

Table 9 Position Controller Modes

## PD Controller Adjustment Procedure

This paragraph presents the step by step procedure for tuning any SAM Drive whose Position Controller is to be configured to operate in PD or PID mode.




Step 1 through step 18 of this procedure are also used when adjusting a PID Controller

---

- 1) Connect the Service PC running SAM Tools to the Service port of the SAM Drive to be tuned.
- 2) Verify SAM Drive to Service PC communications by performing a handshake.
- 3) Setup the trace titled "TUNING.STC" (see Table 5, page 20). TUNING.STC is found in the Promotion "CMDS" subdirectory.

- 4) Activate the control panel titled "TUNING.PAN". TUNING.PAN is found in the Promotion "PANELS" subdirectory.



SConf002.cdr

Figure 24 Tuning Control Panel with Least Significant digit of M\_Stop0\_AB Designated

- 5) On the TUNING control panel, record the current value of the least significant digit of S\_MStop0\_AB (see Figure 24)



Do not forget to record the current value of S\_MStop0\_AB, as it will have to be introduced again at the end of the tuning procedure.

- 6) Now change the least significant digit of S\_MStop0\_AB to "0". This is necessary to prevent position lag from causing a STOP 0 during tuning.
- 7) In the Ri\_RegMode list entry box, select "REG\_MODE\_PDPOS".
- 8) Set R\_IGain, R\_PGain, R\_Inertia, R\_StatFricTorq, and R\_ViscFricTorq = 0.
- 9) If the required speed loop cutoff frequency ( $F_{cv}$ ) and axis inertia (J) are known a starting R\_DGain setting may be calculated as follows:

$$R\_DGain = \frac{4000 \cdot \pi^2 \cdot J \cdot F_{cv}}{M\_StallTorq}, \text{ using the } M\_StallTorq \text{ value displayed on}$$

the control panel.

If not, set R\_DGain = 10.

- 10) Press . Verify that the SAM Drive status indicator displays [1] continuously. If not, a fault/error condition exists which must be eliminated before proceeding.



Before proceeding to next steps, make sure that the motor may move enough in both directions without any danger neither for humans nor for the machine.

- 11) Click on  to produce a short movement of the axis motor. If the motor goes into oscillation, or produces an unacceptable level of audible noise before during or following the movement, reduce the R\_DGain setting by 25%. If there is no oscillation or unacceptable audio noise, increase the R\_DGain setting by 100%.
- 12) Repeat step 10 until the highest setting of R\_DGain without oscillation or unacceptable audible noise is found.




Be continuously aware that the motor is moving, and its load may thus hit machine limits

- 13) Click on , then  to reset position lag to zero.
- 14) Calculate a starting value of R\_PGain as follows:

$$R\_PGain = R\_DGain^2 \cdot \frac{M\_StallTorq}{J} \cdot \frac{10^{-6}}{\pi},$$

where J is the axis total inertia. For M\_StallTorq, use the value displayed on the control panel.

If axis inertia is unknown, set R\_PGain = R\_DGain. If the axis goes into oscillation, reduce R\_PGain by 50%. If oscillation persists, reduce R\_PGain by increments of 50% until oscillation stops.


- 15) If the Trace Control panel (see Figure 6, page 22) is not visible on the monitor, press  on the SAM Tools toolbar to bring in back into the foreground.
- 16) On the Trace Control panel press  to initiate a trace operation.
- 17) On the TUNING control panel, momentarily click and release  to inject a torque disturbance and trigger the trace. Press  on the Trace Control panel when the button becomes active to upload the trace to the monitor. The upload operation requires several seconds.
- 18) On the uploaded trace, note the general shape of POS\_LAG at the positive transition point of TORQ\_FLOW. The objective is to find the best setting of R\_PGain for minimal overshoot and shortest settling time. Referring to the waveforms in Figure 25, increase or decrease R\_PGain and repeat steps 14 through 17 until a satisfactory critically damped response is obtained. Use large increments of R-PGain (50% or so) initially until the upper and lower boundaries of a critically damped response are found, then smaller increments

until the best overall R\_PGain setting is obtained. The trace zoom feature may be used to expand the area of interest.



SAM Tools automatically scale the vertical axis of each trace such that the display fills the available space. When comparing data from successive traces, be sure to note also the vertical axis scaling used.

On the uploaded traces, 180 units of POS\_LAG represent approximately 1 degree of position lag, as measured at the motor shaft.



Sconf003.cdr

Figure 25 Reference Waveforms for Proportional plus Derivative Tuning Step 17.



If adjusting the Controller for PID mode operation: Jump to step 1 of next section.

- 19) Set the Feed-forward compensation (see Feed-forward Compensation on page 49).
- 20) Restore original value of the least significant digit of S\_MStop0\_AB recorded in step 5)
- 21) In the Ri\_RegMode entry box, select "REG\_MODE\_PDPOS".



Upon completion of this procedure, only the tuning parameters in RAM memory have been revised. The tuning parameter values in flash memory remain unchanged. Parameter values in RAM memory are lost upon power-down or resetting of the SAM Drive.

To permanently save the tuning parameters (as well as all other parameters) in flash memory, press the "SAVE PARAMETERS" button on the Tuning control panel. To create a file copy of the SAM Drive parameters see "Uploading Parameters" on page 14.

## PID Controller Adjustment Procedure

This paragraph presents the step by step procedure for tuning any SAM Drive whose Position Controller is to be configured to operate in PID (Proportional plus Integral plus Derivative) mode.

**i**

Keep in mind that using the SAM Feed-forward compensation provides a better accuracy than adding an integral part to the PD controller, when the goal is to follow a “tricky” trajectory (i.e. pick-and-place, cam-profile) AND when load disturbances are relatively small (i.e. 20% of motor rated torque).

The first part of this procedure is identical to the procedure for tuning a proportional plus derivative axis.





- 1) Perform step 1 through step 18 of the “PD Controller Adjustment Procedure” tuning procedure on page 43.
- 2) In the Ri\_RegMode dialog box, select “REG\_MODE\_PIDPOS”.
- 3) If the axis inertia (J) is known a starting value of R\_IGain may be calculated using the following relationship:

$$R\_IGain = \frac{4}{1000 \cdot \sqrt{\pi}} \cdot R\_PGain^{1.5} \cdot \sqrt{\frac{M\_StallTorq}{J}}$$

For M\_StallTorq, use the value displayed on the control panel.

If R\_IGain cannot be calculated, set:

$$R\_IGain = \frac{R\_PGain}{3}$$

- 4) If the Trace Control panel is not visible on the monitor, press  on the SAM Tools toolbar to bring it back into the foreground. Press  to initiate a trace operation.
- 5) On the Tuning Control Panel, momentarily click and release  to inject a torque disturbance and trigger the trace. Press  on the Trace Control window when the button becomes active to upload the trace to the monitor.

- 6) On the uploaded trace, note the general shape of POS\_LAG at the transition points of TORQFLOW. The objective is to find the setting of R\_IGain which reduces POS\_LAG to zero in the shortest time without increasing over-shoot. Referring to the waveforms in Figure 26, increase or decrease R\_IGain and repeat steps 4 through 6 until a satisfactory critically damped response is obtained. Use large increments of R\_IGain (50% or so) initially until the upper and lower boundaries of a critically damped response are found, then smaller increments until the best overall R\_IGain setting is found. The trace zoom feature may be used to expand the area of interest.




Figure 26 Example waveforms for Step 6.

- 7) Set the Feed-forward compensation (see Feed-forward Compensation on page 49).
- 8) Restore original value of the least significant digit of S\_MStop0\_AB recorded in step 5 of the Proportional plus Derivative tuning procedure.
- 9) In the Ri\_RegMode:Parameter Value list entry box, select "REG\_MODE\_PIDPOS".



Upon completion of this procedure, only the tuning parameters in RAM memory have been revised. The tuning parameter values in flash memory remain unchanged. Parameter values in RAM memory are lost upon power-down or resetting of the SAM Drive.

To permanently save the tuning parameters (as well as all other parameters) in flash memory, press the "SAVE PARAMETERS" button on the Tuning control panel. To create a file copy of the SAM Drive parameters see "Uploading Parameters" on page 14.



## Feed-forward Compensation Adjustment Procedure

This procedure is applicable for PD and PID controller modes only. The “Torque” and “Free” controller modes do not utilize feed-forward compensation. The general sequence for setting feed-forward compensation values is weight, “dry friction”, viscous friction then inertia.

- 1) Setup the trace titled “REGPOS.STC”, which is found in the Promotion “CMDS” subdirectory.
- 2) On the Tuning control panel, note the current value of R\_IGain. If R\_IGain is non-zero, record the value then temporarily set R\_IGain = 0.


### Adjusting the Weight compensation

- 3) If the axis weight (or constant force, i.e. produced by a spring) is known, enter the value (in mNm) in the R\_EXTTORQ numeric entry box.

If weight is unknown, read the value of field RF\_TORQUJET. As the motor is stopped while the SAM power stage is on and the SAM PD (or PID) controller has been previously tuned, the produced torque fits mainly to weight. Enter then this value in the R\_EXTTORQ numeric entry box


### Adjusting the “Dry friction” compensation

- 4) If the axis static friction torque is known, enter the value (in mNm) in the R\_STATFRICTORQ numeric entry box. If static friction is unknown, enter zero.
- 5) Setup the control panel for a slow speed move (i.e. Travel\_Speed = 360, Acceleration & Deceleration = 3600, Rel\_Move [deg] = 720).
- 6) On the Trace Control panel, press **START** to initiate a trace operation.
- 7) Click on **REL\_MOVE** to initiate an axis movement. Press **UPLOAD** on the Trace Control panel when the button becomes active to upload the trace to the monitor.
- 8) On the uploaded trace, estimate by eye the average value of POSI\_LAG. Adjust R\_STATFRICTORQ then repeat steps 6 and 7 until average POSI\_LAG is approximately zero (See Figure 27). If POSI\_LAG is > 0, increasing R\_STATFRICTORQ drives position lag in the negative (downward) direction.



Average position lag with no R\_VISCFRICTORQ compensation

Sconf008.cdr




With correct R\_VISCFRICTORQ compensation, average position lag during motion is ~0 (Watch the difference in vertical scales, as it is automatically adjusted to the measure range)

Figure 27 Static friction compensation examples for step 8.

### Adjusting the Viscous friction compensation

- 9) Setup the control panel for a medium speed move (i.e. Travel\_Speed = 7200, Acceleration & Deceleration = 36000, Rel\_Move = 7200).
- 10) If the axis viscous friction torque is known, enter the value (in mNmS/100 Rad.) as **R\_VISCFRICTORQ**.  
If viscous friction is unknown, enter zero.
- 11) On the Trace Control window, press **START** to initiate a trace operation.
- 12) Click on **REL\_MOVE** to initiate an axis movement. Press **UPLOAD** on the Trace Control window when the button becomes active to upload the trace to the monitor.
- 13) On the uploaded trace, estimate by eye the average value of **POS\_LAG** during the constant speed portion of the motion. Adjust **R\_VISCFRICTORQ** then repeat steps 11 and 12 until average **POSITION LAG** is approximately zero during the constant speed portion of the movement. If **POS\_LAG** is > 0, increasing **R\_VISCFRICTORQ** drives position lag in the negative (downward) direction.



Position lag with no **R\_VISCFRICTORQ** compensation

Sconf009.cdr


With correct **R\_VISCFRICTORQ** compensation, average position lag during constant speed is nearly 0.  
(Watch the difference in vertical scales, as it is automatically adjusted to the measure range.)

Figure 28 Viscous friction compensation examples for step 13

### Adjusting the Inertia compensation

- 14) If the axis inertia is known, enter the value (in  $10^{-6} \text{ Kg m}^2$ ) as **R\_INERTIA**.  
If inertia is unknown, enter zero. Set Rel\_Move = 3600.
- 15) On the Trace Control window, press **START** to initiate a trace operation.

- 16) Click on **REL\_MOVE** to initiate an axis movement. Press **UPLOAD** on the Trace Control window when the button becomes active to upload the trace to the monitor.
- 17) On the uploaded trace, estimate by eye the average value of **POS\_LAG** during the acceleration and deceleration portions of the motion. Adjust **R\_INERTIA** then repeat steps 15 and 16 until **POS\_LAG** is approximately zero during the acceleration and deceleration portions of the movement. If **POS\_LAG** is  $> 0$ , increasing **R\_INERTIA** drives position lag in the negative (downward) direction.



Position lag with no **R\_INERTIA** compensation

Sconf010.cdr

With correct **R\_INERTIA** compensation, average position lag during constant speed is nearly 0.  
(Watch the difference in vertical scales, as it is automatically adjusted to the measure range.)

Figure 29 Inertia compensation examples for Step 17

- 18) Repeating the whole procedure may enhance the precision of all feed-forward compensation. Then use other Travel\_Speed, Acceleration and Deceleration settings, such as near the highest normal running speed, acceleration and decelerations to be used in actual operation.

- 19) Restore the value of **R\_I**Gain recorded in step 2.

## Torque Mode Adjustments

- 1) In the **Ri\_RegMode** list entry box, select “**REG\_MODE\_TORQUE**”.

In this mode the Position Controller is totally inactive, and torque commands are supplied by an external source.

## Free Mode Adjustments

- 1) In the **Ri\_RegMode** list entry box, select “**REG\_MODE\_FREE**”.

In this mode the Position Controller is totally inactive, and torque commands are supplied by an external source.

# Emergency STOP Functions

## Overview



---

For additional information on "safe" drive functions and machine level safety and protective functions, refer to the "PAM and SAM System User's Handbook, Part 3 - Safety and Protective Functions".

---

## Error Response

Dedicated hardware in conjunction with extensive monitoring by the SAM Drive firmware detect and respond to error/fault conditions occurring within the drive. Four fault/error response levels are defined:

STOP 0	immediate deactivation of the drive Power Stage
STOP 1	controlled stop (constant deceleration ramp) followed by Power Stage deactivation after a delay
STOP 2	controlled stop (as in STOP 1) but no Power Stage deactivation
USER SIGNAL	additional controlled stop (similar to STOP 2) for non error/fault conditions (as defined by the application)

STOP 0, STOP 1, STOP 2 and USER SIGNAL conditions are treated as "events" by PAM and SAM which means their occurrence initiates a defined response at the application program level. They are represented in the SAM Status and produce an indication on the Front Panel Status Indicator.

An application program can define how a SAM Drive responds to error/fault conditions (i.e. STOP 0, STOP 1 or STOP 2 response). The responses to certain critical fault/error conditions are defined by firmware (forced response) and not user-alterable or maskable.

## User Safety Inputs

On every SAM Drive discrete user safety inputs (**USER STOP 0** and **USER STOP 1**) are provided to permit a fault/error response to be initiated by external circuitry. **USER STOP 0** and **USER STOP 1** are isolated 24 VDC PLC type user inputs. They provide sufficient redundancy to satisfy the criteria for category III safe standstill (per standard EN954-1).

## Fatal Error Output

**FATAL ERROR** is a SAM Drive output (isolated relay contact) which is closed whenever no fatal error condition exists, or when the internal voltage supplies are not available. The **FATAL ERROR** contact normally controls current to a contactor supplying AC power to the SAM system. Upon occurrence of a fatal error, the **FATAL ERROR** contact opens, removing AC power from the SAM system.

## Brake Output Option

The Brake Option is used for controlling an electromechanical brake on a motor equipped with this option. The output is on (conducting) when the power stage is enabled; it is off (not conducting) when the power stage is disabled. As an alternative the Brake Option can also be used for controlling a relay, which short-circuits the motor for quick stopping.

## Status and Display

For each SAM System software version, the detailed list of Front Display codes and Status Bits is shown in ProMotion Help “SAM Status description” topic.

ProMotion Help “SAM Default action mask” topic shows the detailed default values of all status masks. Table 10 shows this list as an example.

			15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MASK	AB HEX	STATUS A																STATUS B																
			24 VDC low		junction over temperature	current regulator fault				stop 0 input active	DC bus overvoltage	power transistor saturation fault	15 VDC supply low	DSP cycle duration beyond limit	DSP Ram Check error	Power stage OFF	No secondary CPU (DSP) acknowledge	High resolution resolver : measure defect	Low resolution resolver : measure defect	Encoder : measure defect	Magnetic angle not valid	Warning : High res. resolver meas. not good (noise)	Brake option error	24 volt supply under warning limit	Aux sensor speed lag greater than limit	Motor thermal protection input active	Motor temperature greater than limit	Motor temperature > warning limit	Cooler temperature > warning limit	Ambient temperature greater than limit	Remote sensor error	Position lag greater than limit		
STOP0	0x59F9F401	X			X	X				X	X	X	X	X	X		X	X	X	X		X										X		
STOP1	0x000000DC																								X	X		X	X	X				
STOP2	0x00000000																																	
USER	0x00000000																																	

			15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MASK	CD HEX	STATUS C																STATUS D																
		Host link transmission failure (hardware)	Host link disabled on corrupted frame	Host link disabled on time-out	Timeout waiting PAM synchronization	Host link communication RESET executed	Invalid host command data received	host cmd not executable due to the current state	Invalid host command code received	STOP1 input active	ref. speed not zero at power on	Option IO : outputs error	Option IO : 24 volt low	Stop0 on stop1 time-out	Application cycle duration beyond period	Main CPU cycle duration beyond limit	Main CPU fault (fault handler)	Error reported	Motor parameters are not valid	Parameter write protected	Parameter given value out of range	Parameters value not accepted	Default value used for other parameters (warning)	Drives parameters are not valid	Stop 0 ordered	Stop 1 ordered	Stop 2 ordered	Out of position limits	Out of speed limits	Trace triggered (reserved for test purpose)	Ram Check error	Firmware corrupted		
STOP0	0x004B2583	X	X	X	X		X	X	X	X	X			X		X	X	X														X	X	
STOP1	0xF7800040																									X								
STOP2	0x00000020																											X						
USER	0x00040000															X																		

Table 10 SAM Default action mask (valid only for System 2.0\_2)

## STOP 0

### Activation

The STOP 0 error response (see Figure 30) can be activated by conditions internal and external to the SAM Drive including:

- **USER STOP 0** input is set to low state
- STOP0 command from the PAM or from SAM Tools (via the service port)
- STOP0 command from an application (sequence) running in the SAM Drive
- A status condition pre-defined by Drive firmware (STOP0 Forced Mask) to initiate a STOP 0 becomes true
- A status condition pre-defined by the application (STOP0 Action Mask) to initiate a STOP 0 becomes true




Figure 30 STOP0 Activation

## Execution

STOP0 causes the following actions (see Figure 31) within the affected axis:

- output transistors of power stage are disabled, removing drive current to the axis motor
- Brake Control (Option) turns off current flow to motor brake
- The STOP0 EXECUTED status bit in SAM Drive Main Status is set
- Speed reference (internal TMP) is decreased to zero
- The STOP2 EXECUTED status bit in SAM Drive Main Status is set
- If the STOP 0 was activated internally by the SAM Drive firmware due to an error condition, the **FATAL ERROR** contact opens



A STOP0 due to activation of the **USER STOP 0** input or a STOP0 command from the PAM or SAM Tools or from an internal sequence does not open the FATAL ERROR contact.





Figure 31 STOP0 Execution

## STOP 1

### Activation

A STOP1 error response (see Figure 32) can be activated by conditions internal and external to the SAM Drive including:

- **USER STOP 1** input is set to low state
- STOP1 command from the PAM or from SAM Tools (via the service port)
- A status condition pre-defined by Drive firmware (STOP1 Forced Mask) to initiate a STOP1 becomes true
- A status condition pre-defined by the application (STOP1 Action Mask) to initiate a STOP1 becomes true
- STOP1 command from an application (Sequence) running in the SAM Drive





## Execution

STOP1 causes the following actions (See Figure 33) within the affected axis:


- Immediate Controlled Stop (axis decelerates to zero speed at a specified rate)
- The STOP1 EXECUTED status bit in SAM Main Status is set
- The STOP2 EXECUTED status bit in SAM Main Status is set

The following actions are taken following execution of the controlled stop:

- Output transistors of power stage are disabled, removing drive current to the axis motor
- Brake Control (Option) turns off current flow to motor brake
- If the STOP 1 was activated internally by the SAM Drive, the **FATAL ERROR** contact opens



A STOP1 due to activation of the **USER STOP 1 Input** or a STOP1 command from the PAM or SAM Tools or from an internal sequence does not open the FATAL ERROR contact.



SAS023\_B.CDR

Normal case:  
Deceleration + Delay < Timeout

Error case:  
Deceleration + Delay > Timeout

Figure 33 STOP1 Execution

## STOP2

### Activation

The STOP2 error response is similar to STOP1 except the Power Stage is not disabled and there is no external user input. STOP2 (see Figure 34) can be activated in the following ways:

- STOP2 command from the PAM or from SAM Tools (via the service port)
- A status condition pre-defined by Drive firmware (STOP2 Forced Mask) to initiate a STOP2 becomes true
- A status condition pre-defined by the application (STOP2 Action Mask) to initiate a STOP2 becomes true
- STOP2 command from an application (Sequence) running in the SAM Drive




Figure 34 STOP2 Activation

Execution

STOP2 causes the following actions (see Figure 35) within the affected axis

- Axis decelerates to zero speed at a specified rate
- The STOP2 EXECUTED status bit in SAM Main Status is set

STOP2 does not affect the Power Stage, Brake Control or FATAL ERROR contact.




Figure 35 STOP2 Execution

## USER SIGNAL

### Activation

The USER SIGNAL error response is similar to STOP2 except that it does not influence directly the SAM Drive operation. It is used only for signaling to PAM (and/or to an internal sequence) that a faulty condition occurred, such as a motor temperature beyond “warning limit”, so that the machine can be slowed-down, or stopped in a controlled way. USER SIGNAL (see Figure 36) can be activated in the following ways:

- A status condition pre-defined by the application (USER SIGNAL Action Mask) to initiate a USER SIGNAL becomes true




Figure 36 USER SIGNAL Activation

### Execution

USER SIGNAL causes the following actions within the affected axis:

- The USER SIGNAL status bit in SAM Main Status is set




Figure 37 STOP2 Execution



A USER SIGNAL does not open the FATAL ERROR contact.

## Fatal Error

**FATAL ERROR** is a SAM Drive output (isolated relay contact set) which is closed indicating no fatal error exists whenever all of the following conditions are satisfied:

- All internal supply voltages are okay (the DC Bus voltage is not considered an internal supply voltage)
- Initialization and internal checking sequences have been successfully completed
- Neither a STOP0 nor STOP1 internal error response has opened the **FATAL ERROR** relay

The **FATAL ERROR** output opens immediately upon occurrence of any of the following events:

- Any internal voltage supply fails
- An internal SAM Drive STOP0 or STOP1 error response opens the **FATAL ERROR** contact

## SAM Brake Option

### Description

The SAM Brake Option is available on all SAM-DA-400-xxB-xxx-xxx. Only the lowest current rated SAM-DA-400-07N-xxx-xxx are not fitted with this option.

This Option is fitted with a solid-state output, which reacts to short-circuit, and also to open circuit (i.e. a brake wire gets broken). Such errors are signalized as "Brake error".




Figure 38 Brake Option Functional Diagram

## Brake handling (brake enabled)

### Automatic handling

At power on the brake is unlocked when the power stage is acknowledged ON.

At power off and STOP0 the brake is simultaneously locked when the power stage is turned off (see section “STOP 0” on page 54).

During STOP1 execution, the brake is locked a few milliseconds before power off action. The delay is corresponding to the value of the field LOCK\_DELAY, default value is 40 ms. In case of STOP1 time-out (occurring while speed does not fall quickly enough to zero) turn off of power stage and brake lock are applied simultaneously (see section “STOP 1” on page 56).

### Manual handling

Lock and unlock method available from panel, when using SAM Tools.

## Brake Object (class Cbrake)

Name	Type	Access	Units	Description
ENABLED	BOOL	RW		option situation
LOCK_STATE	BOOL	RO		ordered state of the brake
LOCK_DELAY	UNS16	RW	ms	delay before locking used by STOP1

Table 11 Brake Object fields

Refer to ProMotion Help “SAM Parameters and Fields access” Topic, and select “Brake fields for host”.

The field ENABLED is initialised to TRUE if:

- Ai\_BrakeOptionInstalled = TRUE  
AND
- Mi\_BrakeEnabled = TRUE

The field is modified from the PAM application according to the ENABLED value of the PAM brake declaration. Modification by panel is also possible.

Methods:

- lock lock of the brake (output is deactivated)
- unlock unlock of the brake (output is activated)

## Parameters related to Brake Option

Name	Type	Units	Description
Ai_BrakeOptionInstalled	UNS16		0 = option not installed 1 = option installed
Mi_BrakeLockDelay	UNS16	ms	used to initialize LOCK_DELAY field default = 40 ms
Mi_BrakeEnabled	BOOL	ms	Indicate motor with brake default = TRUE

Table 12 Brake Object parameters

Refer to ProMotion Help “SAM Parameters and Fields” Topic, and select “System and motor parameters” for host access.

### Brake behavior related to ENABLED field

Hardware Option availability	ENABLED	Behavior
not installed	FALSE	Error report disabled brake_lock = FALSE (logically)
not installed	TRUE	Brake error signaled brak_lock follow order (logically)
installed	FALSE	Error report disabled brake_lock = FALSE (logically)
installed	TRUE	Brake error signaled brak_lock follow order (logically)

Table 13 Brake Object behavior

### Brake error

Bit 10 of status B indicates a brake error (refer to chapter “Status and Display” on page 53).

When set, the brake error bit of status B indicates any of following error conditions:

- short-circuit
- open load condition
- brake output transistor over-temperature

When the brake is enabled, but no hardware option is available (SAM-DA-400-xxN-xxx-xxx), the brake error bit is set. By default, when set, the brake error bit generates a STOP0 (see chapter “STOP 0” on page 53).

# Checking SAM-to-Motor Wiring

## Motor and Feedback Wiring Errors

Errors in the resolver feedback wiring and motor windings wiring between a motor and SAM Drive may produce erratic motion. This procedure provides a systematic method for isolating wiring errors between a Servomotor with standard single speed resolver and a SAM Drive.

Of the 720 possible ways to make resolver feedback connections to a SAM Drive, only one arrangement is correct. Of the remaining 719 incorrect configurations, most produce a Resolver A Measurement Error ([2] & [C] on the SAM Status indicator). A few incorrect resolver wiring configurations produce only erratic motion and - in some cases - an Excess Position Lag error ([2] & [y] on the SAM Status indicator). This procedure is for isolating the causes of erratic motion where no Resolver A Measurement Error is indicated.

The situation with motor winding connections is similar. Only one of the six possible arrangements is correct. The 5 incorrect wiring arrangements cause erratic motion and - in some cases - an Excess Position Lag error ([2] & [y] on the SAM Status indicator).

Incorrect motor or drive parameters can produce symptoms similar to those caused by motor or feedback wiring errors. Prior to performing this procedure, verify that the SAM Drive contains the correct motor and drive parameters (see {reference to downloading motor and drive parameters}) for the axis configuration.

This procedure utilizes the Control Panel "{control panel name}" which is a standard panel provided with SAM Tools.

## Checking Procedure



---

When performing this procedure, the motor may run at any speed and in any direction. Prior to performing this procedure take measures necessary to prevent risk of damage to the driven equipment and injury to personnel.

---

The correct wiring is described in the "PAM and SAM System User's Manual, Part 2 – System Design and Integration". Refer to it whenever necessary.



step	procedure	normal response/indication	corrective action
1	In this procedure the motor shaft must be rotated by hand and it must turn freely. If necessary, uncouple the load from the motor.		
2	Connect SAM Drive on axis to be tested to service PC running SAM Tools	none	none
3	Apply 24 VDC power to SAM Drive.	After initialization SAM Drive status indicator displays [0] continuously	If SAM Drive status indicator displays other than [0] or displays [0] in sequence with other characters, other fault/error conditions exist which must be removed before proceeding with this procedure.
4	Activate the "resolver.pan" control panel.	none	
5	While manually turning the motor shaft in the clockwise direction (as viewed from in front of the motor mounting surface, looking toward the motor) and frequently refreshing the control panel display, monitor the value of POS_RES.	POS_RES increases as the motor shaft is rotated. At some point, POS-RES rolls over to a negative number and increases toward zero as the motor shaft is rotated.	If POS_RES decreases with clockwise rotation of the motor shaft, a wiring error exists in the connections between the motor-mounted resolver and connector X24 on the SAM Drive. Verify SAM Drive to resolver feedback wiring and correct any wiring errors or substitute a known good feedback cable and motor of the same type and model.
6	On the control panel: <ul style="list-style-type: none"> <li>select Regulation Mode = Reg_Mode_Free</li> <li>Set PosReg:TORQ_FLOW = 1000</li> <li>Set CurReg:FREE_FREQ = 0.</li> </ul> If SAM status indicator does not indicate [0], press "Reset STATUS" button. Press "Power ON" button. Goal is enabling SAM to produce a constant current vector locked on the angle CurReg:TETA.	SAM status indicator displays [1] indicating power stage is enabled. The motor shaft rotates to the closest position where it is in alignment with the current vector.	If SAM status indicator displays other than [1], other fault/error conditions exist which must be removed before proceeding.
7	Try turning the motor shaft by hand.	Magnetic flux produced by motor current from the SAM Drive creates an electrical détente, which prevents the motor shaft from turning freely. When rotated a few degrees in either direction and released, motor shaft returns to its original position.	If no resistance is felt, verify all motor windings connections from SAM Drive connector X12 to the motor windings connections  Verify that DC Bus voltage is present at the SAM Drive.
8	On the control panel: <ul style="list-style-type: none"> <li>Set CurReg:FREE_FREQ = 10</li> </ul> SAM produces a current vector which rotates at a frequency of 1.2 Hz (approximately)	Motor shaft rotates slowly in the clockwise direction at constant speed: <ul style="list-style-type: none"> <li>~36 RPM for 4 pole motors</li> <li>~24 RPM for 6 pole motors</li> <li>~18 RPM for 8 pole motors</li> </ul>	If motor shaft rotation is counter-clockwise or the motion is erratic or there is no rotation, check for loose, broken or crossed connections from SAM Drive to motor windings connections

step	procedure	normal response/indication	corrective action
9	On the control panel: • Set CurReg:FREE_FREQ = 0	Motor shaft rotation stops	
10	On the control panel: • Set CurReg:TETA = -16384	Motor shaft rotates into stable position in alignment with current vector at constant angle designated by CurReg:TETA.	
11	On the control panel, refresh panel then read MainSensor:POS_RES.	POS_RES falls within one of the ranges of values listed in Table 15 for the motor type.	<p>If POS_RES is outside one of the ranges of values listed in Table 15 by just a few degrees, increase PosReg:TORQ_FLOW to 2000. This provides additional current to overcome motor friction.</p> <p>If after increasing the value of TORQ_FLOW, POS_RES is still outside one of the ranges listed in Table 15, multiply the deviation by the number of pole pairs for the motor model (see Table 15).</p> <p>Then, if the result is close to 90 or 180, look for a wiring error in the resolver feedback interconnections. A result close to 120 strongly suggests a wiring error in the motor winding interconnections. Verify SAM Drive to motor interconnections or isolate the error by systematic substitution of known good feedback cable, motor windings cable and motor of the same model and type.</p>
12	Restore the SAM Drive to its normal operating configuration by removing 24 VDC power. Wait a few seconds then re-apply power. The SAM drive restores the normal configuration saved in flash memory during initialization		

Table 14 Resolver Feedback and Motor Windings Wiring Verification Procedure

Servomotor type	poles pole pairs	POS_RES range (for Table 14, step 11)
AHD55x4 AHD70x4 AHR92x4	4 poles 2 pole pairs	$0 \pm 1.0$ $\pm 180 \pm 1.0$
AHR115x6 AHR142x6 ABMR190x6	6 poles 3 pole pairs	$0 \pm 1.0$ $+120 \pm 1.0$ $-120 \pm 1.0$
AHD190x8	8 poles 4 pole pairs	$0 \pm 1.0$ $+90 \pm 1.0$ $\pm 180 \pm 1.0$ $-90 \pm 1.0$
All BAUTZ Mxxx types	6 poles 3 pole pairs	$0 \pm 1.0$ $+120 \pm 1.0$ $-120 \pm 1.0$

Table 15 POS\_RES Values for ACC AC Servomotors